

Boiler output is always stated 'from & at 0kPag and fed with water at 100°C. The actual capacity uses the correction factor below for the actual boiler operating pressure and the actual feedwater temperature. The correction factor is divided into the 'from & at' rating.

Gauge Pressure kPa

Water Temp°C	70	140	350	500	700	1000	1200	1500	1800
4	1.18	1.19	1.21	1.21	1.21	1.22	1.22	1.23	1.23
10	1.17	1.18	1.2	1.2	1.21	1.21	1.21	1.22	1.22
16	1.16	1.17	1.18	1.19	1.2	1.2	1.2	1.21	1.21
27	1.14	1.15	1.16	1.17	1.18	1.18	1.18	1.19	1.19
38	1.12	1.13	1.14	1.15	1.15	1.16	1.16	1.17	1.17
49	1.1	1.11	1.12	1.13	1.13	1.14	1.14	1.15	1.15
60	1.08	1.09	1.1	1.11	1.11	1.12	1.12	1.13	1.13
71	1.06	1.07	1.08	1.09	1.09	1.1	1.1	1.1	1.11
82	1.04	1.05	1.06	1.07	1.07	1.08	1.08	1.08	1.09
93	1.02	1.03	1.04	1.05	1.05	1.06	1.06	1.06	1.07
99	1.01	1.02	1.03	1.04	1.04	1.05	1.05	1.05	1.06